# ECE 371 Materials and Devices

12/05/19 - Lecture 26 Ch. 10 – Basic MOSFET Operation

#### **General Information**

- Homework #8 due today.
- Solutions to homework #8 will be posted later today.
- Example final exam posted.
- Review session Friday 12/6 at 3:30 pm in CHTM 103. I will record the session and post on the website.
- Final Exam (Tuesday 12/10, 12:30pm-2:30pm, cumulative but focused on ch. 7,8,10)
  - Two hours long
  - Two sheets of notes (8.5 inch x 11 inch, front and back). Closed book.
  - 4-5 problems mostly covering Ch. 7, 8, 10
  - Several multiple choice and short answer questions covering the whole course
- Reading for next time: review ©

#### FET Modes of Operation

- <u>nMOS</u> (n-channel on p-substrate)
  - $V_T$  < 0 → **depletion mode (on at V\_G = 0)**. Need to apply a negative bias to turn the channel "off".
  - $V_T > 0$  → enhancment mode (off at  $V_G = 0$ ). Need to apply a positive bias to turn the channel "on".
- pMOS (p-channel on n-substrate)
  - $V_T$  < 0 → enhancement mode (off at  $V_G$  = 0). Need to apply a negative bias to turn the channel "on".
  - $V_T > 0$  → depletion mode (on at  $V_G = 0$ ). Need to apply a positive bias to turn the channel "off".
- Whether a device is enhancement mode or depletion mode depends upon the inherent surface band bending, which depends upon the doping,  $\phi_{ms}$ , and the oxide thickness, charge, and dielectric constant

#### n-Channel MOSFETs




Figure 10.34 | Cross section and circuit symbol for an n-channel enhancement mode MOSFET.







Figure 10.35 | Cross section and circuit symbol for an n-channel depletion mode MOSFET.

- Flow of charge is within the inversion layer (channel) adjacent to the oxidesemiconductor interface
- Inversion layer of electrons "connects" source (S) and drain (D)
- Electrons flow from source to drain
- Current flows from drain to source
- Drain and gate biased positive with respect to source
- Enhancement mode (E-mode) requires positive gate voltage to induce the channel
- Depletion mode (D-mode) has inversion channel at zero gate bias

#### p-Channel MOSFETs










Figure 10.36 | Cross section and circuit symbol for (a) a p-channel enhancement mode MOSFET and (b) a p-channel depletion mode MOSFET.

- Holes flow from the source to the drain
- Current flows from the source to the drain
- Inversion layer of holes "connects" source and drain
- Drain and gate biased negative with respect to source
- V<sub>T</sub> negative for E-mode and positive for D-mode

#### **MOSFET:** Basic Operation




Figure 10.37 | The n-channel enhancement mode MOSFET (a) with an applied gate voltage  $V_{GS} < V_T$  and (b) with an applied gate voltage  $V_{GS} > V_T$ .

- For  $V_{GS} < V_T$  and  $V_{DS}$  small, there is no inversion channel
- Drain-to-substrate pn junction is always reverse biased. Reverse current contributes negligible amount to I<sub>D</sub>
- For  $V_{GS} > V_T$  and  $V_{DS}$  positive, current flows from the drain to the source (nMOS)
- Basic MOSFET operation is the modulation of the channel transconductance by the gate voltage ( $V_G o g_d o I_D$ )

# Increasing V<sub>GS</sub> for Small V<sub>DS</sub>





Figure 10.38 |  $I_D$  versus  $V_{DS}$  characteristics for small values of  $V_{DS}$  at three  $V_{GS}$  voltages.


- Gate voltage modulates the charge density and transconductance in the channel
- For V<sub>GS</sub> < V<sub>T</sub>, no current flows in nchannel E-mode FET
- For  $V_{GS} > V_T$ , current flows
- Larger V<sub>GS</sub> gives larger slope of I<sub>D</sub>
   vs. V<sub>DS</sub> curve
- Small V<sub>DS</sub> usually implies operation in the linear region


## Increasing V<sub>DS</sub> for a Given V<sub>GS</sub>



- As V<sub>DS</sub> increases, the voltage across the drain side of the oxide becomes closer to the drain voltage, so the charge density and g<sub>d</sub> are reduced near the drain
- Channel thickness is reduced near the drain
- The I<sub>D</sub> vs. V<sub>DS</sub> curve begins to rollover

## Increasing V<sub>DS</sub> for a Given V<sub>GS</sub>





$$V_{DS(sat)} = V_{GS} - V_T$$

- As V<sub>DS</sub> increases more, the voltage drop across the oxide on the drain side is lowered to the point of V<sub>T</sub> and there is no inversion charge at the edge of the drain
- This point is called the "pinch off" or "saturation" point
- Beyond V<sub>DS(sat)</sub>, the pinch off moves closer to the source and a space charge region is left under the gate near the drain
- The I<sub>D</sub> vs. V<sub>DS</sub> curve saturates
- Electrons reach the end of the inversion layer and are injected into the depletion layer where the built-in E-field sweeps them toward the drain

## I<sub>D</sub> vs. V<sub>DS</sub> for Various V<sub>GS</sub> (n-Channel)




Figure 10.40 | Family of  $I_D$  versus  $V_{DS}$  curves for an n-channel enhancement mode MOSFET.




Figure 10.42 | Family of  $I_D$  versus  $V_{DS}$  curves for an n-channel depletion mode MOSFET.

Linear region for  $0 \le V_{DS} \le V_{DS(sat)}$ 

$$I_D = \frac{W\mu_n C_{ox}}{2L} [2(V_{GS} - V_T)V_{DS} - V_{DS}^2]$$

Saturation region for  $V_{DS} \ge V_{DS(sat)}$ 

$$I_D = \frac{W\mu_n C_{ox}}{2L} (V_{GS} - V_T)^2$$

## p-Channel MOSFET I<sub>D</sub> vs. V<sub>DS</sub>




Figure 10.49 | Cross section and bias configuration for a p-channel enhancement mode MOSFET.

- Drain voltage negative with respect to the source
- Gate voltage negative with respect to the source

• 
$$V_{SD(sat)} = V_{SG} + V_{T}$$

 V<sub>T</sub> is negative for E-mode and positive for D-mode

Linear region for  $0 \le V_{SD} \le V_{SD(sat)}$ 

$$I_D = \frac{W\mu_p C_{ox}}{2L} [2(V_{SG} - V_T)V_{SD} - V_{SD}^2]$$

Saturation region for  $V_{SD} \ge V_{SD(sat)}$ 

$$I_D = \frac{W\mu_p C_{ox}}{2L} (V_{SG} - V_T)^2$$